

The design of this already classic kite has more stability even at low

angles of attack due to a specifically created profile. The progressive

arc means that the kite is rock solid in the air and maintains a guick

THE ACCESS V6 IS OUR ENTRY LEVEL DE-POWER FOIL KITE THAT HAS BEEN DESIGNED TO MAKE THE LEARNING PROCESS OF SNOWKITING AS SAFE AND EASY AS POSSIBLE.







Control System and easy to use Backpack. We recommend adding the

Kompressor Bag to the kite complete option to have your kite packed

and secured as small as possible.



## FEATURES

## **ACCESS V6 FEATURES**

- GREAT FEELING THROUGH THE BAR WITH DIRECT HANDLING WHICH IS VITAL FOR **BEGINNERS**
- SPECIFIC PROFILE TO INCREASE STABILITY AND LOW END POWER TO PROVIDE MORE PULL IN LIGHTER WINDS
- PLANFORM WITH AN INCREASED ARC TO IMPROVE HANDLING AND THE TURNING
- SIMPLE BRIDLE LINE CONFIGURATION REDUCING PARASITIC DRAG TO INCREASE LIGHT WIND PERFORMANCE
- BLOW-OUT-VALVES ON THE UNDER SURFACE HELP AVOID DAMAGE IF THE KITE IS
- VELCRO OPENINGS IN THE TIP TO REMOVE DEBRIS AND SNOW
- DOUBLE PULLEY SPEED-SYSTEM WITH HIGH SPEC RONSTAN ORBIT BALL BEARING
- HIGH QUALITY, EASY TO USE BACKPACK WITH LOADS OF VOLUME
- EXCEPTIONAL HAND CHECKED OZONE FACTORY CONSTRUCTION USING THE HIGHEST QUALITY MATERIALS
- CONTACT-SNOW CONTROL SYSTEM WITH 500KG FRONT/300KG BACK LINES, AND BRAKE STALL HANDLE TO LAND AND RE-LAUNCH THE KITE WITH EASE

## **INTERNAL RE-RIDE RELEASE SYSTEM**


The Internal Re-Ride Release System is the result of intense research and development with the aim to create the safest system on the market. The goal was to have a re-ride system that once activated the kite can easily be re-launched without having to untangle or clear any lines. The new system stalls the kite with an internal line – the kite de-powers instantly without tangling and will sit on the ground ready to re-launch when you're ready again.

Another big advantage of our Internal Re-Ride Release System is the land and secure option. We have added the Secure Loop in the line approx 2m away from the rider. To land the kite with no pull simply pull the 5th line through the chicken loop until you reach the Secure Loop. The kite will stall and fall to the ground without any pull. Use the Secure Loop in the 5th line to keep the kite on the ground - it can either be hooked onto a carabineer on your harness or over the bar horn. This makes landing and packing your kite safe and easy even in high winds.

We thoroughly enjoyed developing and testing the Internal Re-Ride Release System throughout the last season. It has made mountain climbing and packing on top so much more enjoyable, safe, easy and quick for the user.

- The Internal Re-Ride Release System cannot be upgraded to any older kites as it includes lines that are running inside your kite.
- For reverse launch and light wind landing we have kept the Brake Stall Handle between the back leader lines.





Wind range is indicative only based on an average rider weight of 80kg.



